

## 200 Series QC Adapter - 200-QCA-4700

APPLICATION	TOP BOLT	воттом вост	SPECIAL NOTES
1" Bourgault shank without seed boot	1/2" x 2-1/4" no lock washer	1/2" x 2-1/4" no lock washer	Hex-head bolts
1" Bourgault shank with round tube Bourgault seed boot	1/2" x 2-1/4" no lock washer	1/2" x 2" no lock washer	Hex-head bolts, grade 8 required
1" Bourgault shank with square tube Bourgault seed boot	1/2" x 2" no lock washer	1/2" x 2-1/2" no lock washer	Hex-head bolts, grade 8 required
7/8" Bourgault shank without seed boot	1/2" x 2" no lock washer	1/2" x 2" no lock washer	Hex-head bolts
7/8" Bourgault shank with round tube Bourgault seed boot	1/2" x 2-1/4" no lock washer	1/2" x 2" no lock washer	Hex-head bolts, grade 8 required
7/8" Bourgault shank with square tube Bourgault seed boot	1/2" x 2-1/4" no lock washer	1/2" x 2" no lock washer	Hex-head bolts, grade 8 required
3/4" Bourgault shank without seed boot	1/2" x 2" no lock washer	1/2" x 2" no lock washer	Hex-head bolts
3/4" Bourgault shank with round tube Bourgault seed boot	1/2" x 2" c/w with lock washer	1/2" x 1-3/4" no lock washer	Hex-head bolts
3/4" Bourgault shank with square tube Bourgault seed boot	1/2" x 2-1/4" with lock washer	1/2" x 1-3/4" no lock washer	Hex-head bolts
3/4" Ezee-On shank without seed boot	7/16" x 1-3/4"	7/16" x 1-3/4"	Hex-head bolts (see note 3 below)
7/8" Ezee-On shank without seed boot	7/16" x 2"	7/16" x 2"	Hex-head bolts (see note 3 below)

NOTES: 1) Above bolt lengths are determined using prevailing torque side locknuts – grade C. This special locknut is necessary to keep the adapter tight. It is very important to use it, especially in stony or hard ground conditions. 2) Grade 8 bolts are required with the Bourgault 7/8" and 1" shanks where seed boots are involved. If not used, bolt loosening may occur. 3) Shanks with 7/16" holes require the special oversize head hex bolt.

## 200 Series QC Adapter - 200-QCA-4710

APPLICATION	TOP BOLT	BOTTOM BOLT	SPECIAL NOTES
3/4" and 7/8" Flexi-Coil shank without seed boot	7/16" x 2-1/4" no lock washer	7/16" x 2-1/4" no lock washer	Plow bolt (see note 2 below)
7/8" Flexi-Coil shank with 5649 seed boot	7/16" x 2-1/2" no lock washer	7/16" x 3-7/8" no lock washer	Plow bolt (see note 2 below)
1/2" Morris Challenger shank without seed boot	3/8" x 1-3/4" no lock washer	3/8" x 1-3/4" no lock washer	Plow bolt (see note 2 below)
5/8" Morris Challenger shank without seed boot	3/8" x 2" no lock washer	3/8" x 2" no lock washer	Plow bolt (see note 2 below)
7/8" Morris shank without seed boot	7/16" x 2-1/4" no lock washer	7/16" x 2-1/4" no lock washer	Plow bolt (see note 2 below)
9/16" CIL shank without seed boot	3/8" x 2" no lock washer	3/8" x 2" no lock washer	Plow bolt (see note 2 below)
5/8" John Deere shank without seed boot	7/16" x 2" no lock washer	7/16" x 2" no lock washer	Plow bolt (see note 2 below)
3/4" Degelman shank	7/16" x 2-1/4" no lock washer	7/16" x 2-1/4" no lock washer	Plow bolt (see note 2 below)
9/16" Wil-rich shank without seed boot	1/2" x 2" no lock washer	1/2" x 2" no lock washer	Plow bolt

## 200 Series QC Adapter - 200-QCA-5010

APPLICATION	TOP BOLT	BOTTOM BOLT	SPECIAL NOTES
1" shank without seed boot or wedge	1/2" x 2-1/2" with lock washer	1/2" x 2-1/2" with lock washer	Plow bolt
1-1/4" shank without seed boot seed boot or wedge	1/2" x 2-3/4" with lock washer	1/2" x 2-3/4" with lock washer	Plow bolt

NOTES: 1) Above bolt lengths are determined using prevailing torque side locknuts – grade C. This special locknut is necessary to keep the adapter tight. 2) Shanks with 3/8" and 7/16" holes require special oversize head plow bolts. 3) When bolting a seed boot, usually it is the bottom bolt which bolts the seed boot to the shank; the top bolt should remain the same length as listed above. If the seed boot cross section at the point the bolt goes through is 1/8" thick or less, use the same bolt length as above without the lock washer. If the seed boot cross section at the point the bolt goes through is greater than 1/8", increase bolt length by adding the measured cross section of the seed boot at the point the bolt goes through to the above lengths.