


682-ASY-2063 & 682-ASY-2064 ASSEMBLIES

SIDE BAND



682-ASY-2064

682-ASY-2063 - LEFT

682-ASY-2064 - RIGHT

PART#		682-ASY-2063 G	682-ASY-2063M M	682-ASY-2063P P	682-ASY-2063MP M P	682-ASY-2064 G	682-ASY-2064M M	682-ASY-2064P P	682-ASY-2064MP M P
1	682-KNF-2063	■							
2	682-KNF-2063M		■						
3	682-KNF-2063MP				■				
4	682-KNF-2063P			■					
5	682-KNF-2064					■			
6	682-KNF-2064M						■		
7	682-KNF-2064MP								■
8	682-KNF-2064P							■	
9	880-BSH-1130	■	■	■	■	■	■	■	■
10	682-DEF-1000	■	■	■	■	■	■	■	■
11	680-ACC-0001*								
12	880-CPL-2500			■	■			■	■
13	695-HCL-1220		■		■		■		■

NOTE 11: Accessory 680-ACC-0001 is needed when used on an edge on Concord. See page 89 for more information.