

BOLT LENGTH CHART

410 Series QC Adapter – 410-QCA-5000

APPLICATION	TOP HOLE	BOTTOM HOLE	SPECIAL NOTES
1" Bourgault shank without seed boot	1/2" x 2-1/2"	1/2" x 2-1/2"	Hex-head
1" Bourgault shank with Bourgault splitter seed boot 6505-42	1/2" x 2-1/2"	1/2" x 2-3/4"	Hex-head
1-1/4" Bourgault shank without seed boot	1/2" x 2-3/4"	1/2" x 2-3/4"	Hex-head
1-1/4" Bourgault shank with Bourgault splitter seed boot 6505-42	1/2" x 2-3/4"	1/2" x 3"	Hex-head

410 Series QC Adapter – 410-QCA-5010

APPLICATION	TOP HOLE	BOTTOM HOLE	SPECIAL NOTES
1" shank without seed boot or wedge	1/2" x 2-1/2"	1/2" x 2-1/2"	Hex-head
1-1/4" shank without seed boot or wedge	1/2" x 2-3/4"	1/2" x 2-3/4"	Hex-head

NOTES: 1) Above bolt lengths are determined using prevailing torque side locknuts – grade C. This special locknut is necessary to keep the adapter tight. 2) When bolting a seed boot, usually it is the bottom bolt which bolts the seed boot to the shank; the top bolt should remain the same length as listed above. If the seed boot cross section at the point the bolt goes through is 1/8" thick or less, use the same bolt length as above without the lockwasher. If the seed boot cross section at the point the bolt goes through is greater than 1/8", increase bolt length by adding the measured cross section of the seed boot at the point the bolt goes through to the above lengths. 3) When bolting an adapter using a wedge, a wedge will only be used when using the 410-QCA-5010 adapter on 43° and 47° chisel plows. Measure the cross section of the wedge at both bolt holes and add this amount to the above numbers. Remember that the measured cross section will be different at each hole in the wedge.

600 Series Quick Tip Knives

APPLICATION	TOP HOLE	BOTTOM HOLE	SPECIAL NOTES
For 47° and 50° applications, no wedge is needed			
1-1/4" Bourgault shank	1/2" x 2-3/4"	1/2" x 2-3/4"	Hex-head bolt, regular nut and lock
1" Bourgault shank	1/2" x 2-1/2"	1/2" x 2-1/2"	Hex-head bolt, regular nut and lock
7/8" Bourgault shank	1/2" x 2-1/2"	1/2" x 2-1/2"	Hex-head bolt, regular nut and lock
3/4" Bourgault shank	1/2" x 2-1/4"	1/2" x 2-1/4"	Hex-head bolt, regular nut and lock
1-1/4" Flexi-Coil shank	1/2" x 2-3/4"	1/2" x 2-3/4"	Hex-head bolt, regular nut and lock
1-1/4" Morris shank	1/2" x 2-3/4"	1/2" x 2-3/4"	Hex-head bolt, regular nut and lock (see note 1 below)
1" John Deere shank	1/2" x 2-1/2"	1/2" x 2-1/2"	Hex-head bolt, regular nut and lock
7/8" Shulte shank	1/2" x 2-1/2"	1/2" x 2-1/2"	Hex-head bolt, regular nut and lock
3/4" Degelman shank	1/2" x 2-1/4"	1/2" x 2-1/4"	Hex-head bolt, regular nut and lock
For 43° applications, wedge 400-WDG-0700 is required			
1" Morris shank for NH ₃ knives	1/2" x 3" no lock washer	1/2" x 2-3/4" no lock washer	Hex-head, regular nut
1" Morris shank for granular knives	1/2" x 3" no lock washer	1/2" x 2-3/4" no lock washer	Hex-head, regular nut
1-1/4" CIL shank, 2-1/2" hole center-to-center	1/2" x 3-1/4" c/w no lock washer	1/2" x 2-3/4" no lock washer	Hex-head, regular nut
1-1/4" IH shank	1/2" x 3-1/4"	1/2" x 3"	Hex-head bolt, regular nut and lock (see note 2 below)
3/4" Case IH vibra chisel shank	1/2" x 2-3/4"	1/2" x 2-1/2"	Hex-head bolt, regular nut and lock

NOTES: 1) Some material may have to be ground off the bottom of the 1-1/4" Morris shank (front face) to get the knife holder to seat down tight against the shank. 2) The 1-1/4" IH shank will fit the NH₃ knives, but not the granular knife. 3) All knives come with holes to accommodate 1/2" bolts. If cultivator shanks have 7/16" holes, substitute 7/16" bolts for 1/2" and use a flat washer on the bolt head.